

B-Formatting Examples

%.%	Value + Status of the Out slot
%out.value%	<u>Value</u> of the Out slot
%out.status%	<u>Status</u> of the Out slot
%Hours%	Get the total elapsed time in hours
%Minutes%	Get the total elapsed time in minutes
<u>EXAMPLE:</u> <i>Burn Time = %Hours% HRS</i> <i>(Static Text: Burn Time = – blank space – total elapsed time in hours – blank space – Static Text: HRS)</i> Burn Time = 568 HRS <i>(Use either Hours OR Minutes – not both, since they both display total time.)</i>	
%displayName%	Display name of the slot
%parent.name%	Name of the parent component (1 level up)
%parent.parent.name%	Name of parent of the parent component (2 levels up)
<u>EXAMPLE:</u> <i>For the LightingSystem control relay:</i> <i>%parent.name% > %displayName%</i> LightingSystem > ControlRelay <i>This will display the display name of the child component (ControlRelay) preceded by the name of the parent object (the folder called Lighting System).</i>	
Text = %out.value% Text > %out.status% Text: %.%	Insert ANY text before or after % to provide a labeling function w/o having to produce a separate Display Name Label. <i>All text outside % signs is static.</i>
%property.value% %property.value%	Two (or more) bFormats strung together separated by a space – can be something other than the “Out” slot.
<u>EXAMPLE:</u> <i>%high.value% / %low.value% > > %weatherSummary%: %precipChance%</i> 65 F / 44 F >> Rain Likely: 67.0%	
%anyproperty.value%	Value of any component's property
%user()%	Currently logged in user

%alarmData.sourceName% > %alarmData.highLimit%!	High Alarm Limit Message Text
%alarmData.sourceName% < %alarmData.lowLimit%!	Low Alarm Limit Message Text
%alarmData.sourceName% is back in normal range	Alarm Back To Normal Message Text
<u>EXAMPLE:</u> %alarmData.sourceName% > %alarmData.highLimit%! Hot Water Temp > 81 °F!	